9.2 EXTERIOR SECTION



(1) EXTERIOR SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	MAIN Assy	DWG1660
	2	SDCB Assy	DWX2980
	3	USBA Assy	DWX3043
	4	ACIN Assy	See Contrast table (2)
	5	•••••	
	6	JACB Assy	DWX2988
	7	SRVA Assy	DWX2948
⚠	8	POWER SUPPLY Assy	DWR1463
	9	14P FFC	DDD1478
	10	40P FFC	DDD1479
	11	10P FFC	DDD1480
	12	13P FFC	DDD1484
	13	Connector Assy	DKP3844
	14	Connector Assy 12P	DKP3845
	15	•••••	
	16	Cord with Plug	DE007VE0
	17	Damper	CNV6011
	18	Power Knob	DAC2484
	19	DM Screw (FTC)	DBA1260
	20	Earth Spring	DBH1398
	21	Float Spring (G5)	DBH1494
NSP	22	Slicon Rubber D5 L	DEB1456
	23	Bottom Packing	DEC3209
	24	Mecha Plate	DNH2339
	25	MAIN PCB Stay	DNH2854
	26	Inlet Shield	DNH2856
	27	Front Plate	DNH2857
	28	SD Stay	DNH2858
	29	Shield Case	DNH2859
	30	SWPS Stay	DNH2890
	31	Chassis	See Contrast table (2)
	32	Servo Cover	DNK5492
	33	Insulator Assy	DXB2057
	34	Rivet (3 x 4.5)	RBM-003
	35	Bottom Plate	See Contrast table (2)
	36	Jack Cover	DEC3205
	37	Cord Clamper (Steel)	RNH-184
	38	•••••	
	39	Screw	BBZ30P060FTB
	40	Screw	BPZ30P080FNI
	41	Screw	BPZ30P080FTB
	42	SD Earth Plate	DNH2925
	43	SD Earth Spring	DBK1357
	44	Main Cover	DEC3258
	45	FFC Cushion	DEC3248
	46	EMC Sheet	DEC3259
	47	Vessel Cushion A	DEC2852
	48	Ferrite Core	BTX1037
	49	Cushion (FC)	DEC3249
	50	Tape	DEC3053

(2) CONTRAST TABLE

CDJ-2000/CUXJ, SYXJ8, FLXJ, KXJ5 and AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-2000 /CUXJ	CDJ-2000 /SYXJ8	CDJ-2000 /FLXJ	CDJ-2000 /KXJ5	CDJ-2000 /AXJ5
	4	ACIN Assy	DWR1475	DWR1453	DWR1453	DWR1453	DWR1453
	31	Chassis	DNK5444	DNK5324	DNK5445	DNK5448	DNK5447
	35	Bottom Plate	DNH2893	DNH2852	DNH2904	DNH2903	DNH2902